"Custom Scanner Edition"

Turn the **"Zone knob"** to change **"Zones"**

Orange button not connected to anything

A-B-C rotating plate used to set-up the "custom" scan list

1. *Keep on* "**A**" *for normal operations*
2. *The "noogie" to rotate the plate is found on the back part of the plate .*

Push to Talk

Speaker-mic. has a **Rotating "Swivel Clip" in the back**

Speaker –Microphone Volume knob

Zone #

Signal Strength   Scan On

time
Z battery

1 **DOH-BT**
CHAN
CLCK   SCAN

Talk Group
(channel)

Screen Light On & Off

Turning "Scanner" On & Off

Turn On: Press the ⚫ button… the screen shows two options…. press the ⚫ button to turn the Scanner "On" *a* "Z" *should appear in the upper screen.*

Turn Off: …Press the ⚫ button **twice** *and the "Z" will disappear from the screen.*

Custom Scanner Programming

Turn the **A-B-C**- rotating plate to "**B**"
A flashing " ⬚ will appear in the screen.
Bring up the channel you want to add or delete.
Press ⚫ button to **select** a channel to add *(a "Z" should appear).*
Bring up your next channel.
Press ⚫⚫ button to **delete** a channel *(the "Z" should disappear).*
To review your selections keep pressing the ⚫ **recall** button.
When done building your list Rotate the **A-B-C** plate back to "**A**".

Scanner Tips:

- Each Zone has a pre-programmed "hard" scan list installed by the dealer for your facility. Just turn to that zone & put "**On**" the scanner to scan those channels.
- The "custom" scan list (10 channels max) can go in between zones & include digital & analog channels.
- You have a few seconds to talk directly to a channel that pops up on your scanner, before it reverts back to scanning channels again.

4-way Toggle Switch

to change **"Talk Groups"** or **"Channels"**

How to Change "Talk Groups" *(also known as "channels")*

1. Turn the **Zone knob** to the **"Zone"** where that Talk Group is located.
2. Press the ⚫⚫ button *(you will see a "talk group" blinking).*
3. Click the **4-way Toggle Switch** **"left or right"** to change the **"Talk Group"**.
4. When you get to the channel you want press the **"home"** button and your **"Talk Group"** / **Channel"** is now changed.

Motorola Digital Radios Hospitals/Clinics "Base" Template

	Zone 1 — DOH (Dept. of Health)		Zone 2 — EMS WEST (Hospital Emergency Dept./Ambulance)		Zone 3 — EMS EAST (Hospital Emergency Dept./Ambulance)		Zone 4 — INT Interagency (Police/Fire/Ambulance)		Zone 5 — EMERGENCY		Zone 6 — STATE AID		Zone 7 — V-Tac (VHF National Common Tactical Radio Channels)		Zone 8 — Hospital/Clinic
1	DOH-BT — DOH Bioterrorism	1	Cnt EMS — Central Region EMS	1	SC EMS — South Central Region EMS	1	SF INT — Sioux Falls Area INT	1	SP OP1 — Special Operations 1	1	ST AID1 — State AID - 1	1	M/A RPTR	1
2	DOH 1 — DOH Region 1	2	Rbd EMS — Rosebud Region EMS	2	Chm EMS — Chamberlain Region	2	Tkr INT — Turkey Ridge Area INT	2	SP OP2 — Special Operations 2	2	ST AID2 — State AID - 2	2	M/A DIR	2
3	DOH 2 — DOH Region 2	3	MAR EMS — Martin Region EMS	3	Wag EMS — Wagner Region EMS	3	Ver INT — Vermillion Area INT	3	SP OP3 — Special Operations 3	3	ST AID3 — State AID - 3	3	V-CALL 10	3
4	DOH 3 — DOH Region 3	4	PR EMS — Pine Ridge Region EMS	4	Prk EMS — Parkston Region EMS	4	Trp INT — Tripp Area INT	4	SP OP4 — Special Operations 4	4	ST AID4 — State AID - 4	4	VTAC 11	4
5	DOH 4 — DOH Region 4	5	SH EMS — Southern Hills Region EMS	5	Ynk EMS — Yankton Region EMS	5	Mit INT — Mitchell Area INT	5	SP OP5 — Special Operations 5			5	VTAC 12	5
		6	RC EMS — Rapid City Region EMS	6	SE EMS — Southeast Region EMS	6	Brk INT — Brooking Area INT	6	SP OP6 — Special Operations 6			6	VTAC 13	6
		7	NH EMS — Northern Hills Region	7	SF EMS — Sioux Falls Region EMS	7	Wtn INT — Watertown Area INT	7	SP OP7 — Special Operations 7			7	VTAC 14	7
		8	LEM EMS — Lemmon Region EMS	8	Mad EMS — Madison Region EMS	8	Web INT — Webster Area INT	8	SP OP8 — Special Operations8			8	VTAC 17	8
		9	EB EMS — Eagle Butte EMS	9	Mit EMS — Mitchell Region EMS	9	Isb INT — Isabel Area INT	9	NWS-W — Nat. Wx Service - West			9	VTAC 17D	9
		10	EMS 1 — Extra EMS Channel 1	10	Hur EMS — Huron Region EMS	10	Abr INT — Aberdeen Area INT	10	NWS-C — Nat. Wx Service - Central/NE			10	VTAC33	10
		11	EMS 2 — Extra EMS Channel 2	11	Brk EMS — Brookings Region EMS	11	Red INT — Redfield Area INT	11	NWS-SE — Nat. Wx Service - Southeast			11	VTAC34	11
		12	EMS 3 — Extra EMS Channel 3	12	Wtn EMS — Watertown Region EMS	12	Hur INT — Huron Area INT	12	STFIR 1 — State Fire - 1			12	VTAC35	12
		13	EMS 4 — Extra EMS Channel 4	13	NE EMS — Northeast Region EMS	13	Mil INT — Milbank Area INT	13	STFIR 2 — State Fire - 2			13	VTAC36	13
		14	EMS 5 — Extra EMS Channel 5	14	Abr EMS — Aberdeen Region EMS	14	Chm INT — Chamberlain Area INT	14	STFIR 3 — State Fire - 3			14	VTAC37	14
		15	EMS 6 — Extra EMS Channel 6	15	Red EMS — Redfield Region EMS	15	WIN INT — Winner Area INT	15	Wx-1			15	VTAC38	15
		16	EMS 7 — Extra EMS Channel 7	16	NC EMS — North Central EMS	16	PIR INT — Pierre Area INT	16	Wx-2			16	VFIRE21	16
		17	EMS 8 — Extra EMS Channel 8			17	Mob INT — Mobridge Area INT	17	Wx-3			17	VFIRE22	17
						18	PHL INT — Philip Area INT	18	Wx-4			18	VFIRE23	18
						19	MAR INT — Martin Area INT	19	Wx-5			19	VFIRE24	19
						20	BIS INT — Bison Area INT	20	Wx-6			20	VFIRE25	20
						21	RC INT — Rapid City Area INT	21	Wx-7			21	VFIRE26	21
						22	SH INT — Southern Hills Area INT					22	VMED28	22
						23	NH INT — Northern Hills Area INT					23	VMED29	23
						24	FTH INT — Faith Area INT					24	VLAW31	24
												25	VLAW32	25
												26	SAR1	26

Black – digital channels   **Red** – analog *(Non-digital)* channels   **SP OP 1** - (monitored 24/7)   **Wx** channels - Rx-only   **V-TAC** - Common channels