

Ebola

Donning of PPE - PAPR and Coverall Checklist

Room# _____

Healthcare Personnel Name: _____ Date: _____ Time: _____

Trained observer – CLEAN DONNING AREA
<input type="checkbox"/> Use a checklist
<input type="checkbox"/> Healthcare worker has attended to personal needs (hydration/restroom)
<input type="checkbox"/> Remind that you will be reviewing the steps aloud and to repeat back
<input type="checkbox"/> Remind steps should be done slowly and methodically
Remove personal clothing and items – visual inspection
<input type="checkbox"/> Clean surgical scrubs/disposable clothing
<input type="checkbox"/> Shoes (closed toe and heel – no holes, washable I.E. rubber or plastic)
<input type="checkbox"/> No personal items (pager, phone, watches, jewelry, pens, ID badge, etc.)
<input type="checkbox"/> Hair pulled back from face, neck and back
<input type="checkbox"/> Nails short – no longer than ¼”
Visually inspect the PPE ensemble (HC worker with trained observer watching)
<input type="checkbox"/> Serviceable condition
<input type="checkbox"/> All required PPE and supplies available
<input type="checkbox"/> Sizes selected are correct for the healthcare worker
<input type="checkbox"/> PAPR – Follow all manufacturer instructions
<input type="checkbox"/> Test PAPR battery and airflow
<input type="checkbox"/> Ensure PAPR hood is intact – no visible cracks
<input type="checkbox"/> Reviews donning sequence with the healthcare worker aloud step-by-step
Perform Hand hygiene – Allow hands to dry
<input type="checkbox"/> In between fingers
<input type="checkbox"/> Backs of hands
<input type="checkbox"/> Wrists
Boot covers (sit on chair)
<input type="checkbox"/> Ensure all areas of foot are covered (boot covers snug over ankle)
<input type="checkbox"/> Put on inner gloves
Put on coverall - Inspect for integrity
<input type="checkbox"/> Proper sizing
<input type="checkbox"/> Put on coverall with zipper in the front
<input type="checkbox"/> Tuck inner gloves under sleeve of coverall
<input type="checkbox"/> Thumb hooks or taping of coverall (tab created folding tape over at end for removal)
Put on PAPR (attach hose to PAPR battery pack)
<input type="checkbox"/> The Trained Observer will hold the respirator at the small of the back while HC worker fastens the belt around waist snugly and secures any loose straps
<input type="checkbox"/> The PAPR battery pack/ filter unit should be on the outside of the coverall to ensure proper airflow
Put on outer glove (trained observer may need to assist)
<input type="checkbox"/> Cuffs over sleeves of coverall
Put on PAPR Hood
<input type="checkbox"/> Put on the single use (disposable) PAPR hood that that fully covers the neck and extends over the shoulders
<input type="checkbox"/> Attach PAPR tube to the PAPR hood, making sure the tube is snapped and fits and then turn on the PAPR battery pack and filter unit
<input type="checkbox"/> Put on apron (if vomiting or diarrhea)
<input type="checkbox"/> The healthcare provider should have an unobstructed field of vision through the hood. A mirror in the room can be a useful tool for the healthcare provider while donning PPE to do a self-check.

Donning checklist v1: 15 November 2014

http://www.cdc.gov/vhf/ebola/hcp/ppe-training/PAPRespirator_Coveralls/donning_01.html

Signature of Trained Observer _____